

Australia **Coaster** Gen1



**Vehicle manual.**

Try our online **help hub**.



helphub.starv.com



helphub.jucy.com

# Coaster Gen1 vehicle **MANUAL**

## Contents

---

<b>Description of keys.....</b>	<b>03</b>
<b>Vehicle equipment.....</b>	<b>04</b>
<b>Starting the vehicle.....</b>	<b>05</b>
<b>Windows &amp; blinds .....</b>	<b>06</b>
<b>12-volt electrical system .....</b>	<b>07</b>
<b>Fresh water tank .....</b>	<b>08</b>
<b>Grey water tank .....</b>	<b>09</b>
<b>Portable toilet cassette .....</b>	<b>10</b>
<b>Portable gas stove .....</b>	<b>11</b>
<b>Tap &amp; sink.....</b>	<b>14</b>
<b>Fridge .....</b>	<b>15</b>
<b>Lights .....</b>	<b>16</b>
<b>USB Chargers.....</b>	<b>17</b>
<b>Bed .....</b>	<b>18</b>
<b>Storage .....</b>	<b>22</b>
<b>Diesel fuel .....</b>	<b>23</b>



helphub.starrv.com



helphub.jucy.com

# 01. Description of keys

---



## **IGNITION KEY:**

Use for:

1. Start your vehicle



helphub.starrv.com



helphub.jucy.com

## 02. Vehicle equipment

---

### **FIRE EXTINGUISHER**

Each vehicle is equipped with a dry chemical fire extinguisher, meticulously selected to address both type B fires (involving grease and liquids) and type C fires (involving electrical elements). To deploy the extinguisher effectively, grasp the ring situated atop the bottle, direct the nozzle towards the top of the flames, and press down the lever firmly. Guide the nozzle from side to side to cover the entire width of the base of the flames.



\*Fire extinguisher is located under the sink.



helphub.starrv.com



helphub.jucy.com

## 03. Starting the vehicle

---

Gear stick must be in PARK and your foot on the pedal in order for the vehicle to start.



*Gear stick in parking mode.*

The dashboard will display a 'P' indicating that the vehicle is in park. Start the vehicle using the ignition key.



*Gear stick in driving mode*

With your foot still on the brake pedal, pull the gear stick down into the 'D' position. The dashboard will display a 'D' indicating that the vehicle is in drive.

Disengage the hand brake by pulling it down. A red exclamation mark will disappear from the dashboard. To engage the handbrake, pull the handbrake up. A red exclamation mark will appear.

### NOTE –

Handbrake is on the left-hand side of the driver seat. Do not forget to disengage the handbrake before you drive.





helphub.starrv.com



helphub.jucy.com

## 04. Windows & blinds

---

The vehicle is equipped with privacy curtains for the rear window and side window as well as flyscreen curtains for the front windows.

To attach the curtains, locate the correct curtain and magnetically attach to the metal surface of the window surround.





helphub.starrv.com



helphub.jucy.com

## 05.12-volt electrical system

Your vehicle has two batteries. One in the engine compartment and one in the rear of the cabin. The battery inside the cabin is also called your domestic battery. The engine compartment battery is located under the driver's seat.

The domestic battery operates the water pump, fridge & interior lights. The domestic battery is charged by the alternator when the vehicle is being driven.



Diagram A

The 12-volt electrical panel is located at the rear of the vehicle in the kitchen area under the sink. To turn it on, push the yellow switch (Diagram A) up until it clicks.




Diagram B

This panel operates the water pump and light and must be turned on at all times to operate any device on the 12-volt system.

To turn the 12-volt electrical panel off, press the red button (Diagram B) and the yellow switch will flick down.

**IMPORTANT – It is recommended that the vehicle is driven for 4-6 hours a day for the domestic battery to continue to operate the 12-volt system.**



## 06. Fresh water tank

---

The freshwater tank is located under the bed/dining area on the right side.

### To fill the freshwater tank:

1. Unscrew the compartment that says "Fresh water only".
2. Remove the cap from the water inlet.
3. Place the end of the water hose into the tank and connect the hose.



**Note:** Do not use too much pressure as the tank must be vented when filling. In the event of an air bubble, simply remove the hose, reinsert it and fill slowly again. The tank is full when the water starts to overflow from the water inlet.



## 07. Grey water tank

---

The grey water holding tank collects wastewater from the kitchen sink.

### To empty the grey water tank:

1. Collect the grey water hose from the storage compartment.
2. Connect the hose to the outlet. Make sure it is firmly attached.
3. Place the other end of the hose into the dump station disposal opening.
4. Open the tank by pulling the lever located on the side of the outlet.
5. Once the grey water is empty, close the lever & remove the hose and stow away in the storage compartment.



Should the grey water tank become obstructed during your journey, we recommend inserting a hose into the grey water outlet as far as it reaches. Turn on the hose to its highest pressure setting and direct the flow of water into the tank until it reaches full capacity. Once achieved, withdraw the hose, facilitating the flow of grey water. If needed, repeat this process until the obstruction is cleared.



helphub.starrv.com



helphub.jucy.com

## 08. Portable toilet cassette

---



It is highly recommended to regularly empty the toilet cassette, and it is mandatory to empty and clean it before returning the vehicle to the depot.

After emptying the toilet cassette, rinse it thoroughly and repeat the emptying process. Then, add a toilet chemical along with half to a litre of water.



## 09. Portable gas stove

---

The vehicle is equipped with a portable butane gas stove which can be found in the kitchen compartments in a black carry case.

Inside the vehicle, the cooker is to be only used on the kitchen stove but can be used outside on a side table.

The cooker is designed to be used for very short periods – no longer than fifteen minutes at a time.

This cooker is not designed for use with pans larger than 200mm.



1. To start remove gas cooker from the black carry case and place on a flat surface.



2. Open cartridge cover and place gas cartridge in.



helphub.starrv.com



helphub.jucy.com



3. Turn the ignition knob to "OFF" and set the cartridge lock lever to "UNLOAD".

4. Open the cartridge cover, slide the gas cartridge, top end first and with its notch up, in the compartment.




5. Align cartridge collar notch with the locator tab on the gas cooker as per photo.



6. Push and turn the knob to anti-clockwise past the ⚡ position until a click is heard.

**Please Note:** If the burner fails to light, immediately turn the ignition knob to "OFF" position and restart again.

The flame can be controlled by turning the ignition knob between the "HIGH" and "LOW" position.



Try our online **help hub**.



helphub.starrv.com



helphub.jucy.com



Turn the ignition knob to “OFF” to shut off fuel supply.

Wait until the flame is fully extinguished before performing the next step.

Raise the cartridge lever to “UNLOAD” and remove the gas cartridge from the compartment.

Do not leave the gas bottle inside the gas cooker when not in use.





helphub.starrv.com



helphub.jucy.com

## 10. Tap & sink

---



The vehicle comes equipped with a water system. To operate the tap, ensure the yellow switch on the main control panel is flicked up and the orange switch located on the wall in the dining area is on and illuminated. Hold the tap handle down for the water to release.



Try our online **help hub.**



helphub.starrv.com



helphub.jucy.com

# 11. Fridge

---

The fridge in your vehicle operates via the 12-volt system. To operate the fridge, ensure the yellow switch on the main control panel is flicked up.



**IMPORTANT** – It is recommended that the vehicle is driven for 4-6 hours a day for the domestic battery to continue to operate the 12-volt system.

Try our online **help hub**.



helphub.starrv.com



helphub.jucy.com

## 12 Lights

---

To operate the cabin lights, turn on using the light switch.

Switching to the left turns off the light, switching to the middle allows the light to turn on when the doors are opened and switching to the right turns the light on.





helphub.starrv.com



helphub.jucy.com

## 13. USB Chargers

---

The vehicle is equipped with 2 USB PowerPoints & 1 USB car charger in the dining area

These run off the 12-volt battery and will only work if the main power button is switched on.





helphub.starrv.com



helphub.jucy.com

# 14. Bed

The vehicle is equipped with 1 double bed that also serves as the dining area during the day.


To make the bed, follow the below steps:



1. To make the bed remove the seat squabs off the seat base.



2. Remove the loose plywood from the left & right-hand side.



3. Once the seat squabs & loose plywood have been removed. Open the hinged seat base to the vertical position against the tabletop.



4. The bed base should now look like this, as per photo.


Try our online **help hub.**



helphub.starrv.com



helphub.jucy.com



5. Bend the top part of the plywood down on the left & right hand side of the seat base.



6. Once you have completed step 5, lift the middle table up, and tuck the left & right seat base underneath the middle table, press down on middle table to see if it is secured.



7. Place the left & right-hand loose plywood with the cut-outs, can now be placed between the seat back alloy strip and on top of the vertical section matching the corresponding cut-outs to hold the panel in place.



8. Make sure the plywood has been placed in correctly & is flat & secured. Put weight on the left & right-hand side of each plywood so its firm.

Try our online **help hub.**



helphub.starrv.com




helphub.jucy.com



9. Bed base should now be secured and filled with the bed squabs. Ensure the sink is covered and wiped down before placing bed squabs on.



10. Rear bed base to be placed on the kitchen bench.



11. Rear bed base squab placed firmly on the kitchen bench & now place the rest of the bed squabs on to the bed.



12. Place the remaining 3 bed squabs on to the bed, ensure the squab with the 4 velcro tabs is placed in the middle.



helphub.starrv.com



helphub.jucy.com



13. Place the middle bed squab in the middle with the 4 velcro tabs place flat and firm on the middle part of the bed.



14. Place the left- & right-hand bed squabs onto each side of the bed, ensure you secure all 4 velcro's together so the bed squabs are all in one.



15. Once all bed squabs are firmly placed and secured, bed is now ready.

Try our online **help hub.**



helphub.starrv.com



helphub.jucy.com

# 15. Storage

---

The vehicle has a dedicated storage area under the left seat of the bed/dining area and under the seat in the cabin area.



Try our online **help hub**.



helphub.starrv.com



helphub.jucy.com

## 16. Diesel fuel

---

The vehicle accepts diesel fuel only. DO NOT refill the vehicle with any other fuel or fluid. The diesel tank cap is marked with DIESEL on it and can be opened by unscrewing the diesel cap. The fuel filling location is located next to the passenger door.

Once filled with diesel, place the fuel cap on the inlet and turn the cap to lock it.

**IMPORTANT:** The vehicle accepts diesel fuel only. If you fill the vehicle with unleaded, water or AdBlue, please do not start the engine and call JUCY Roadside Assistance immediately.