

Australia **Coaster** Gen 2



Vehicle manual.

Try our online **help hub**.



helphub.starv.com



helphub.jucy.com

Coaster vehicle **MANUAL**

Contents

Description of keys.....	03
Vehicle equipment.....	04
Starting the vehicle	05
Windows & blinds	06
12-volt electrical system	07
Freshwater tank.....	08
Greywater tank.....	09
Portable toilet cassette	10
Portable gas stove	11
Tap & sink.....	14
Fridge	15
Lights	16
USB Chargers.....	17
Luton table	18
Bed	19
Storage	20
Diesel fuel	21

Try our online **help hub.**



helphub.starrv.com



helphub.jucy.com

01. Description of keys



IGNITION KEY:

Use for:

1. Start your vehicle



helphub.starrv.com



helphub.jucy.com

02. Vehicle equipment



FIRE EXTINGUISHER

Each vehicle is equipped with a dry chemical fire extinguisher, meticulously selected to address both type B fires (involving grease and liquids) and type C fires (involving electrical elements). To deploy the extinguisher effectively, grasp the ring situated atop the bottle, direct the nozzle towards the top of the flames, and press down the lever firmly. Guide the nozzle from side to side to cover the entire width of the base of the flames.

*Fire extinguisher is attached to the interior of the vehicle



helphub.starrv.com



helphub.jucy.com

03. Starting the vehicle

Gear stick must be in PARK and your foot on the pedal in order for the vehicle to start.



Gear stick in parking mode

The dashboard will display a 'P' indicating that the vehicle is in park. Start the vehicle using the ignition key.



Gear stick in driving mode

With your foot still on the brake pedal, pull the gear stick down into the 'D' position. The dashboard will display a 'D' indicating that the vehicle is in drive.

Disengage the hand brake by pulling it down. A red exclamation mark will disappear from the dashboard. To engage the handbrake, pull the handbrake up. A red exclamation mark will appear.



NOTE –

Handbrake is on the left-hand side of the driver seat. Do not forget to disengage the handbrake before you drive.



helphub.starrv.com



helphub.jucy.com

04. Windows & blinds

WINDOWS

The vehicle is equipped with privacy curtains on the rear windows and in the front cabin.

These blinds can be rolled up when not in use.



To open the windows on board your vehicle, turn the vent handles inwards. Push the window out and click the latch in place. The window has a mosquito net and a sun blackout blind. These can be used separately. To use the mosquito net, pull the white blind down using the handle indents. To use the sun blackout blind, pull the blind up using the handle indents.





helphub.starrv.com



helphub.jucy.com

05.12-volt electrical system



Your vehicle has two batteries. One in the engine compartment and one in the rear of the cabin. The battery inside the cabin is also called your domestic battery. The engine compartment battery is located under the driver's seat.

The domestic battery operates the water pump, esky & interior lights. The domestic battery is charged by the alternator when the vehicle is being driven.

The 12-volt electrical panel is located on the rear of the vehicle in the kitchen area. To turn it on, switch the power button so the green light is illuminated.

This panel operates the water pump and light and must be turned on at all times to operate any device on the 12-volt system.

IMPORTANT – It is recommended that the vehicle is driven for 4-6 hours a day for the domestic battery to continue to operate the 12-volt system.



helphub.starrv.com



helphub.jucy.com

06. Freshwater tank



The freshwater tank is located in the rear of the vehicle, in the kitchen area.



To fill the freshwater tank:

1. Unscrew the “Fresh water only” compartment.
2. Remove the cap from the water inlet.
3. Place the end of the water hose into the tank and connect the hose to the tap to fill the vehicle with fresh water.

Note: Do not use too much pressure as the tank must be vented when filling. In the event of an air bubble, simply remove the hose, reinsert it and fill slowly again. The tank is full when the water starts to overflow from the water inlet.



07. Greywater tank

The grey water holding tank collects wastewater from the kitchen sink.

To empty the greywater tank:

1. Collect the grey water hose from the storage compartment.
2. Connect the hose to the outlet. Make sure it is firmly attached by pulling down the silver levers on each side of the attachment.



3. Place the other end of the hose into the dump station disposal opening.
4. Open the tank by turning the blue lever so it is parallel with the pipe and wait for it to empty.
5. Once the grey water is empty, close the lever & remove the hose and stow away in the storage compartment.

Should the grey water tank become obstructed during your journey, we recommend inserting a hose into the grey water outlet as far as it reaches. Turn on the hose to its highest pressure setting and direct the flow of water into the tank until it reaches full capacity. Once achieved, withdraw the hose, facilitating the flow of grey water. If needed, repeat this process until the obstruction is cleared.



helphub.starrv.com



helphub.jucy.com

08. Portable toilet cassette



It is highly recommended to regularly empty the toilet cassette, and it is mandatory to empty and clean it before returning the vehicle to the depot.

After emptying the toilet cassette, rinse it thoroughly and repeat the emptying process. Then, add a toilet chemical along with half to a litre of water.



helphub.starrv.com



helphub.jucy.com

09. Portable gas stove

The vehicle is equipped with a portable butane gas stove which can be found in the kitchen compartments in a black carry case.

Inside the vehicle, the cooker is to be only used on the kitchen stove but can be used outside on a side table.

The cooker is designed to be used for very short periods – no longer than fifteen minutes at a time.



1. To start remove gas cooker from the black carry case and place on a flat surface.



2. Open cartridge cover and place gas cartridge in.



helphub.starrv.com



helphub.jucy.com



3. Turn the ignition knob to "OFF" and set the cartridge lock lever to "UNLOAD".

4. Open the cartridge cover, slide the gas cartridge, top end first and with its notch up, in the compartment.




5. Align cartridge collar notch with the locator tab on the gas cooker as per photo.



6. Push and turn the knob to anti-clockwise past the ⚡ position until a click is heard.

Please Note: If the burner fails to light, immediately turn the ignition knob to "OFF" position and restart again.

The flame can be controlled by turning the ignition knob between the "HIGH" and "LOW" position.



Try our online **help hub**.



helphub.starrv.com



helphub.jucy.com



Turn the ignition knob to "OFF" to shut off fuel supply.

Wait until the flame is fully extinguished before performing the next step.

Raise the cartridge lever to "UNLOAD" and remove the gas cartridge from the compartment.

Do not leave the gas bottle inside the gas cooker when not in use.





helphub.starrv.com



helphub.jucy.com

12 Tap & sink

The vehicle comes equipped with a water system. To operate the tap, turn on the 12-volt control panel by pressing the power button so the green power button illuminates green. The tap switch also needs to be illuminated green for the tap to work.



Try our online **help hub.**



helphub.starrv.com



helphub.jucy.com

13. Fridge

The fridge in your vehicle operates via the 12-volt system. To operate the fridge, switch on the power button so it illuminates green.

IMPORTANT – It is recommended that the vehicle is driven for 4-6 hours a day for the domestic battery to continue to operate the 12-volt system.





helphub.starrv.com



helphub.jucy.com

14. Lights

To operate the cabin lights, turn on the 12-volt control panel by pressing the power button so the green power button lights up green.

The switches for the lights are located in the cabin of the vehicle, on the wall across from the bed.

Flicking the switch upwards illuminates the red light, flicking the switch downwards illuminates the white light.



Try our online **help hub**.



helphub.starrv.com



helphub.jucy.com

15. USB Chargers

The vehicle is equipped with four USB power points in the kitchen area and four USB power points in the cabin area.

These run off the 12-volt battery and will only work if the main power button is switched on.



helphub.starrv.com



helphub.jucy.com

16. Luton table



To disassemble the table, pull handle 1 out and rotate right.

Clip back in and rotate left: repeat to loosen and remove the tabletop.

Repeat for handles 2 & 3 and remove the table leg.





helphub.starrv.com



helphub.jucy.com


17. Bed

The vehicle is equipped with one double bed that also serves as the dining area during the day.

To make the bed, follow the below steps:



1. Remove table from the dining area (see Luton table for removal).



2. Remove all cushions from the dining area. Using the table that was removed in step 1, place the table in the middle of the bed area. In the storage compartment under the bed, there will be another flatbed extension. Place this on the end of the bed (see photo on left)



3. Place cushions back on the bed.

Try our online **help hub.**



helphub.starrv.com



helphub.jucy.com

18. Storage

The vehicle has a dedicated storage area under the bed/ dining area, as well as various drawers/ cupboards throughout the vehicle to store personal items.





helphub.starrv.com



helphub.jucy.com

19. Diesel fuel

The vehicle accepts diesel fuel only. DO NOT refill the vehicle with any other fuel or fluid. The diesel tank cap is marked with DIESEL on it and can be opened by unscrewing the diesel cap. The fuel filling location is located next to the passenger door.

Once filled with diesel, place the fuel cap on the inlet and turn the cap to lock it.

IMPORTANT: The vehicle accepts diesel fuel only. If you fill the vehicle with unleaded fuel, water or AdBlue, please do not start the engine and call JUCY Roadside Assistance immediately.

